



INSTALLATION ADVISORY

March 4, 2014

To: Versico Authorized Contractors

ATTENTION TO FOREMAN AND PROJECT SUPERVISORS

LOW-VOC PRIMER INSTALLATION TECHNIQUE

As many of you are aware, there are significant differences in how the Low-VOC products function compared to the standard products. Understanding these differences is a key to improving your productivity and quality of installation.

Versico recently updated its Low-VOC Primer Technical Data Bulletin highlighting some key installation advice.

In order to achieve the best results, it is important to set your quick-applied or pressure-sensitive product into the primed area as soon as possible after the primer flashes off.

You will notice that by setting the products into the primer shortly after flash-off that the green strength is increased dramatically. Get your crews into the habit of applying quick-applied and pressure sensitive products right after flash-off to minimize the chance of contamination from wind-blown dust or debris and help guard against getting caught in the rain.

Many of you already follow this practice...keep up the good work!

Please share this information with your crews to achieve the best results.

Sincerely,

A handwritten signature in black ink that reads 'Ronald L. Goodman'.

Ronald L. Goodman
Marketing Manager, EPDM and Fleece Roofing Systems

A SINGLE SOURCE FOR SINGLE-PLY ROOFING

Tel: **800.992.7663** Fax: 717.960.4036 Web: **www.versico.com**